



Getting Started Guide
دليل بدء التشغيل
Guia de Introdução
Guide de prise en main

GOLD MONSTER 1000

Australia & Asia Pacific
+61 8 8238 0888
minelab@minelab.com.au

Europe & Russia
+353 21 423 2352
minelab@minelab.ie

Middle East & Africa
+971 4 254 9995
minelab@minelab.ae

North, South & Central America
+1 630 401 8150
info@minelabamericas.com

4901-0226-4
this equipment.
By Minelab Electronics could void the user's authority to operate
this equipment.

OPERATING FREQUENCY
The detector is configured to operate at a fundamental operating frequency of 45 KHz.

WARNING: Any changes or modifications not expressly approved by Minelab Electronics could void the user's authority to operate this equipment.

- Consult the dealer or an experienced radio/TV technician for help that to which the receiver is connected
- Connect the equipment into an outlet on a circuit different from
- Increase the separation between the equipment and receiver
- Reorient or relocate the receiving antenna

Following measures:
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

NOTE: Class B Devices
Information to the User (FCC Part 15, 105)




COMPLIANCE
This product has a 2 year limited warranty from the time of purchase. Please refer to www.minelab.com for further warranty information. Register this product online at register.minelab.com

WARRANTY TERMS
Ce produit est garanti de 2 ans à partir de la date de son achat. Pour plus d'informations sur la garantie, veuillez consulter le site www.minelab.com. Enregistrer ce produit en ligne sur le site register.minelab.com.
Este produto tem um limite de garantia de 2 anos a partir da data de sua compra. Consulte em www.minelab.com para obter maiores informações sobre a garantia. Registre este produto online em register.minelab.com.



Re-initialiser les réglages d'usine
أعادة ضبط المصنع
Factory Reset

Press and hold for 10 seconds
Appuyez pendant 10 secondes
Pressione e mantenha assim por 10 segundos
اضغط واسمّر في الضغط لمدة 10 ثوانٍ

Control Panel | لوحة التحكم | Panneau de commande | Paineil de controle



9 Quick Ground Balance Long Press | ميزان أرضي سريع ضغطة طويلة
Équilibre au sol rapide Appui Long | 快速地面平衡 长按
Balanço Rápido do Solo Longa Impresa



- EN**
- Gold Chance Indicator
 - Battery Level
 - Sensitivity Adjust (1-10)
 - Auto Sensitivity (11)
 - Auto + Sensitivity (12)
 - Error Indicator
 - Volume Adjust (1-6)
 - Detect Mode
 - Ground Balance
 - Power

- AR**
- مؤشر احتمالية الذهب
 - مستوى شحن البطارية
 - ضبط حساسية (1-10)
 - حساسية أوتوماتيكية (11)
 - حساسية + أوتوماتيكية (12)
 - مؤشر الأخطاء
 - ضبط شدة الصوت (1-6)
 - اسلوب الكشف
 - توازن الأرض
 - التشغيل


- FR**
- Indicateur de probabilité d'or
 - Niveau de charge batteries
 - Réglage de la sensibilité (1-10)
 - Sensibilité automatique (11)
 - Sensibilité + automatique (12)
 - Indicateur d'erreur
 - Réglage du volume (1-6)
 - Mode de détection
 - Équilibre au sol
 - Marche/Arrêt

- PT**
- Indicador de Oportunidade de Ouro
 - Nível de bateria
 - Ajuste de sensibilidade (1-10)
 - Sensibilidade automática (11)
 - Sensibilidade + automática (12)
 - Indicador de erro
 - Ajuste do volume (1-6)
 - Modo de detecção
 - Balanço Terrestre
 - Ligar

Configurções de Fábrica

- Turn On
شغل الجهاز
Mise en route
Ligar
- Auto noise cancel
الإلغاء الأوتوماتيكي للضوضاء
Élimination automatique des interférences
Cancelamento de ruído automático

- Begin gold detecting
إبدء البحث عن الذهب
Commencer à détecter de l'or
Iniciar a detecção de ouro



Assembly


التجميع

Montage

Montagem


1

Screw mid, lower & upper shafts together
اربط القضيب الأوسط والسفلي والعلوي سوياً
Vissez les manches inférieur, intermédiaire et supérieur ensemble
Aparafuse as hastas intermediária, inferior e superior juntas




2

Attach lower shaft to coil
قم بتثبيت القضيب السفلي في الملف
Reliez le manche inférieur à la tête de détection
Fixe a haste na bobina




3

Attach control box to upper shaft
قم بتثبيت صندوق التحكم في القضيب العلوي
Reliez le boîtier de commande au manche supérieur
Fixe a caixa de controle na haste superior




4

Attach armrest to upper shaft
قم بتثبيت مسند الذراع في القضيب العلوي
Reliez le repose bras aumanche supérieur
Fixe o apoio de braço na haste superior




5

Wrap cable around shaft & connect to control box
قم بلف الكابل حول القضيب وتوصيله بصندوق التحكم
Enroulez le câble autour du manche et connectez-le au boîtier de commande
Enrole o cabo em torno da haste e conecte-o à caixa de controle




6

Insert batteries
قم بتثبيت البطاريات
Insérez les piles
Insira as baterias



Connect headphones
قم بتوصيل سماعة الرأس
Connectez le casque audio
Conecte os fones de ouvido




Universal Shaft Adaptor Embout de manche universel

وصلة عصي الحمل الشاملة Adaptador Universal da Haste

Detecting Basics Fondamentaux de la détection

مبادئ الكشف عن المعادن Detecção Básica


Alternative plastic shaft or broomstick
قضيب بلاستيكي بديل أو عصا مكنسة
Possibilité de manche en plastique ou de manche à balai
Haste de plástico opcional ou cabo de madeira



1

Insert shaft into yoke
ركب القضيب في القارية
Insérez la manche dans l'embout
Insira a haste no encaixe

Check washers
افحص الوردات
Vérifiez les rondelles
Verifique as aruelas





2

Follow steps 2-6 of Assembly
اتبع الخطوات 2-6 من خطوات التجميع
Suivez les étapes 2 à 6 du montage
Siga as etapas de 2 a 6 para a Montagem



Battery Charging Chargement des batteries

شحن البطارية Carregar a bateria



This file was downloaded from the metal detecting and gold prospecting archives at <https://www.detectorprospector.com/files/>

Items are archived for historical and informational purposes. Many items are out of date and any prices in particular should be verified. Specifications for older models may have changed.

Find more catalogs, brochures, manuals, guides, and more for download at [DetectorProspector.com](https://www.DetectorProspector.com) along with some of the best metal detecting and gold prospecting [forums](#) on the internet.